

Century Series 4 Humidifier



Operating Instructions & Safety Guide

ANDREWS
HEAT FOR HIRE

0800 211 611
andrews-sykes.com

General Safety

- Humidifiers are for internal use only.
- This equipment should only be used by a competent person who has read and understood these instructions.
- Check condition of equipment before use. If unit is showing any signs of damage contact your supplier immediately.
- Never operate this equipment if you are ill, feeling tired or under the influence of alcohol or drugs.
- Do not use in wet or damp conditions. Keep all vents and grills clear of obstructions.
- Keep children and animals away from the humidifier.
- Never leave them alone in a room where the units are in use.
- Make sure equipment is switched **off** and unplugged after use.

Electrical Safety

- This unit requires a 230-volt electrical supply and plugs into standard domestic 13 amp socket.
- Always inspect plugs and power cables for damage before plugging into power supply.
- DO NOT USE IF ANY DAMAGE IS FOUND.
- Ensure cables are installed to prevent hazards. If an extension lead is used, ensure it is of the correct standard and fully uncoiled before use.
- Cables must not be laid in wet or damp areas.
- Do not move equipment while operating. Do not pull equipment by the power lead.
- It is recommended that the electrical supply to this equipment is protected by an RCD.

Getting started and operation

Fig 1
Position equipment on level ground.
Connect to electrical supply



Fig 1

Fig 2
Remove barrel from unit, fill with clean water and place barrel back inside the unit



Fig 2

Fig 3
Select required fan speed and set humidistat to required RH setting



Fig 3

Fig 4
When water level is low, fan will cut out. To restart, simply refill barrel as in step 2.




Fig 4