

DE 65 Electric Fan Heater



Operating Instructions & Safety Guide

ANDREWS
HEAT FOR HIRE

0800 211 611
andrews-sykes.com

General Safety

- Electric heaters are for internal use only.
- This equipment should only be used by a competent person who has read and understood these instructions.
- Check condition of equipment before use. If unit is showing any signs of damage contact your supplier immediately.
- Never operate this equipment if you are ill, feeling tired or under the influence of alcohol or drugs.
- Do not use in wet or damp conditions.
- Keep all vents and grilles clear of obstructions.
- Keep children and animals away from electric heaters. Never leave them alone in room where the units in use.
- Make sure equipment is switched off and unplugged after use.

Electrical Safety

- This unit requires a 415 volt 3ph / Earth electrical supply.
- Plugs into BS4343 4 pin 32 amp socket.
- Always inspect plugs and power cables for damage before plugging into power supply.
- DO NOT USE IF ANY DAMAGE IS FOUND.
- Ensure cables are installed to prevent hazards.
- If an extension lead is used, ensure it is of the correct standard and fully uncoiled before use.
- Cables must not be laid in wet or damp areas.
- Do not move equipment while operating.
- Do not pull equipment by the power lead

Getting started and operation

Position equipment on level ground

Connect to electrical supply (fig 1)

Switch on power (fig 2)

- 0 - Off
- 1 - Fan Only.
- 2 - 6.5kW
- 3 - 9.8kW
- 4 - 13kW

Switch off power and unplug unit when finished with.

