

# DE 95 Electric Fan Heater



## Operating Instructions & Safety Guide



0800 211 611  
andrews-sykes.com

### General Safety

- Electric heaters are for internal use only.
- This equipment should only be used by a competent person who has read and understood these instructions.
- Check condition of equipment before use. If unit is showing any signs of damage contact your supplier immediately.
- Never operate this equipment if you are ill, feeling tired or under the influence of alcohol or drugs.
- Do not use in wet or damp conditions.
- Keep all vents and grills clear of obstructions.
- Keep children and animals away from electric heaters. Never leave them alone in room where the units in use.
- Make sure equipment is switched off and unplugged after use.

### Electrical Safety

- This unit requires a 415 volt 3ph / Earth electrical supply.
- Plugs into BS4343 4 pin 32 amp socket.
- Always inspect plugs and power cables for damage before plugging into power supply.
- DO NOT USE IF ANY DAMAGE IS FOUND.
- Ensure cables are installed so as not to cause a hazard.
- If an extension lead is used, ensure it is of the correct standard and fully uncoiled before use.
- Cables must not be laid in wet or damp areas.
- Do not move equipment while operating.
- Do not pull equipment by the power lead

### Getting started and operation

Position equipment on level ground

**Fig 1**  
Connect to electrical supply

**Fig 2**  
Switch on power

0 - Off  
1 - Fan Only.  
2 - 10kW  
3 - 15kW  
4 - 20kW



**Fig 1**



**Fig 2**

Switch off power and unplug unit when finished with.